


High Voltage System


System Diagram

- System Diagram of Prius




System Diagram

- System Diagram of RX400h




HV Battery

- Battery Smart Unit
 - Transmit the HV battery information to the THS ECU




Inverter Assembly

- System Diagram




Inverter Assembly

- Inverter
 - Converts DC ↔ AC




Inverter Assembly

- Boost Converter (Variable-voltage System)
 - Converts DC 288V ↔ DC 650V




Inverter Assembly

- Boost Converter (Variable-voltage System)
 - System Diagram




Inverter Assembly

- Variable-voltage System
 - Voltage boost-up operation




Inverter Assembly

- Variable-voltage System
 - Voltage boost-up operation



Inverter Assembly


- Variable-voltage System
 - Voltage reduction operation (when charging)



Inverter Assembly


- Variable-voltage System

- Voltage reduction operation (when charging)



Inverter Assembly


- Variable-voltage System
 - Voltage reduction operation (when charging)



Motor Control


- Variable Voltage Control

To minimize loss, the system voltage is controlled according to the operating condition of MG2




Motor Control

- Variable Voltage Control
 - Evaluation in vehicle (Full throttle)




Motor Control

- Variable Voltage Control
 - Evaluation in vehicle (Accelerator pedal ON/OFF)





Motor Control

- Increase of Utilization Voltage
 - Control range of voltage control





Inverter Assembly

- Inverter Operation
 - Motor drive





Inverter Assembly

- Inverter Operation
 - Motor drive





Inverter Assembly

- Inverter Operation
 - Motor drive




Inverter Assembly

- Inverter Operation
 - Regeneration





Inverter Assembly

- Inverter operation





Inverter Assembly

- MG1 / MG2
 - Stator coil polarity and magnetic strength changes moment by moment





Inverter Assembly

- MG1 / MG2
 - Rotor of permanent magnet is rotated via attraction / repulsion from stator coil





Inverter Assembly

- MG1 / MG2




Inverter Assembly

- MG1 / MG2




Motor Control

- Rotor magnets




Inverter Assembly

- Prius




Inverter Assembly

- GUU, GVU and GWU




IGN ON



Engine running




Inverter Assembly


- Gate control of IGBT



Motor Control



- Increase of Utilization Voltage
 - Kinds of voltage control

| | Low Speed | Middle Speed | High Speed |
|------------------|---|--|---|
| Current Waveform |  |  |  |
| Utilization Rate | 0 – 0.61 | 0.61 – 0.78 | 0.78 |
| Feature | Small Torque Fluctuation | Output Improvement | |



Motor Control

- Resolver



THS II


- Resolver operation

[Resolver_A.ppt](#)

[Resolver_M.ppt](#)


Inverter Assembly

- RX400h




Motor Control

- System Diagram (PRIUS)




Motor Control

- System Diagram (RX400h)




Inverter Assembly

- DC – DC Converter
 - Converts DC 288V → DC 12V




Inverter Assembly

- DC – DC Converter
 - Operation



Inverter Assembly

- DC – DC Converter
 - Operation



Auxiliary Battery


- Vehicle conditions when auxiliary battery low voltage

| Vehicle Condition | Auxiliary Battery Voltage | |
|---|---------------------------|---------------|
| | PRIUS | RX400h |
| Shift position indicator doesn't light up <i>(It can turn to READY ON)</i> | 9.5 V or less | 9.5 V or less |
| It cannot turn to READY ON | 7 V or less | 8.6 V or less |

Auxiliary Battery


PRIUS

- Vehicle conditions when auxiliary battery low voltage




Service Point for RX400h

- Fail-safe
 - DC-DC converter (for auxiliary battery) malfunction



Inverter Assembly


- MG ECU
 - Controls the inverter components in accordance with the signals from the THS ECU



THS-II Control System

- Motive Force Calculation

- Target Motive Force - Engine Motive Force = MG2 Motive Force





Toyota Hybrid Synergy Drive[®]

Service & safety

Content

1. Disable Vehicle for Service
 - Procedure
 - **READY indicator**
 - **Service Plug**
 - Precautions
 - **Insulated gloves**
 - **Waiting period before service (discharge time HV condensers)**
 - **“CAUTION” sign during service**
 - **High Voltage colour code**
2. Hybrid vehicle storage
3. Emergency response guide
4. Roadside Assistance

Disable Vehicle for Service

Warning:



- **READY** = Engine may run



- **Never** assume the Prius is **shut OFF**, simply **because** it is **silent**.
- **Always observe** the instrument cluster for the **READY indicator** status to verify whether the vehicle is ON or shut OFF.



Disable Vehicle for Service




- Push POWER button to turn **READY OFF**
→ **System Main Relays (SMR)** turn OFF:
 - To disconnect HV battery from HV circuit
 - **Disconnect 12V battery** 
 - Remove HV battery **Service Plug**
 - Cuts the high voltage circuit (wear insulated gloves) 
 - Place Service Plug in **your pocket**
 - Wait **5 minutes** (discharge HV condensers of Inverter)
- Note: Collision control:**
- *SRS Airbag sensor + sensor in Inverter turn SMR relays OFF*



Disable Vehicle for Service

Service Plug:

- **Disable high voltage** current from the HV battery
- **Cuts** high voltage circuit between No.19 and No.20 module
- **125 A fuse** is integrated




Service Plug



Disable Vehicle for Service

Precautions:

- Wearing HV insulated gloves while removing the Service plug.
- Place it **in your pocket**.
(Prevent other technicians from reinstalling it while you are servicing the vehicle)
- **Wait 10 minutes** before touching any HV terminals or connectors.
(to **discharge HV condensers** inside the inverter)
- All high-voltage wire harness connectors are colored **orange**.



Disable Vehicle for Service

HV Battery

- Service Plug
 - Installation



Connect the service plug



Turn the lever



Push the lever downward until the “click” is heard

Caution: Wear insulated gloves

Disable Vehicle for Service

Precautions:


- Before wearing HV insulated gloves:
 - Ensure they are **not cracked, ruptured, torn** or damaged in any other way.
 - Do **not wear wet** insulated gloves.
- When servicing the vehicle:
 - Do **not wear metal objects** like self-propelling pencil, ruler or other objects that may drop and cause a short circuit.
- Before touching a **bare HV terminal**:
 - **Ensure** the terminal has **no voltage** using a **multimeter** whilst wearing HV insulated gloves.
- After **disconnecting or exposing** a HV connector or terminal:
 - **Insulate** it immediately using **insulation tape**.
- The screw of a **HV terminal** should be tightened firmly to the **specified torque**. Both insufficient and excessive tightening torque can cause failure.

Disable Vehicle for Service : HV system awareness

Precautions:

- Draw attention to the vehicle on which the HV system is being inspected or repaired by placing a

**“CAUTION:
high voltage do
not touch during operation”**
sign.



- **After servicing HV system** and before reinstalling Service Plug, check again that:
 - you have not left a part or tool inside
 - the HV terminal screws are firmly tightened
 - the connectors are correctly engaged.
- All **high-voltage** wire harness connectors are colored **orange**.

Disable Vehicle for Service

Do **not** place HV battery **upside down** while removing and installing it.

Install Service Plug before starting the system:

- Starting Hybrid system with Service Plug removed may damage the vehicle.

Car storage & battery maintenance



HV
Battery
(201,6 V)

Auxiliary 12 V
Battery
(Sealed-type)

12 V Power Source
Backup Unit
for ECB brakes

Auxiliary 12 V battery

- Supplies power to headlights, audio, other accessories and all ECU's
- Special for Prius
- Maintenance-free




Car storage & battery maintenance



Auxiliary 12 V battery


- Before delivery:
 - Fully charge 12 V battery in slow charge (**max. 3,5 A**)
- In order to store the car for **more than 10 days**:
 - **Disconnect** wire harness **from jump start terminal** of 12 V battery (prevent discharge due to current to ECU's and Smart key system)
 - **Close the cover** of the jump start terminal and **fasten the wire harness to the protruding part of the cover** (short circuit!)



Car storage & battery maintenance

HV battery

- Every **two months**:
 - Keep “Hybrid system” ON (**READY ON**) for **30 minutes**
(in order to charge HV battery and auxiliary battery - static current drop)




Battery maintenance by customer

Recommended

HV battery / 12 V battery charging by **customer**




+



- Charge every **2 weeks** for +/- 30 min.
 - By starting the hybrid system (**“ON”**)
 - All **electrical components OFF**
- Fully **READY** charged **HV battery** can hold charge for +/- **60 days**

Car storage & battery maintenance



Message prompt in multi-display

Charging HV battery pack

- The HV battery will not be charged in the “N” position
- Generator operates only in “P”, “D” or “B” position
- In traffic jam: select “D”.
- If vehicle stopped for a long time: select “P” position!

Car storage & battery maintenance

HV battery capacity

- EV mode:

- +/- 1 km < 45 km/h
on a level road
(with standard state of charge
of the HV battery)



EV mode switch
(LHD model)

Car storage & battery maintenance



Auxiliary
battery

Power source
backup unit

Power source backup unit:

- Supplies electric power to brake system when voltage power supply decreases
- When power mode turned OFF:
 - Power Source Backup unit starts to discharge
 - Is charged every trip

Mechanical fail-safe function

- Conventional (*non-assisted*) hydraulic brake on front wheels

Car storage & battery maintenance

Too much discharged HV battery

- If HV battery voltage becomes too low:
 - Hybrid Synergy Drive® system stops operating to protect HV battery
- 201,6 V **HV battery** can **NOT** be **jumpstarted** !
- **Engine** is **started** by the 500 V “generator/motor” **using** 201,6 V **HV battery**
- **No HV battery charger** for NMSC’s
- Vehicle **cannot be push-started** !
(similar to an automatic transaxle vehicle)

Extended Warranty Coverage


Hybrid system:

- 8 years
- 160 000 km

Emergency Response

Emergencies involving the Prius may be handled **like other automobiles**, **except** for the following situations:

- Extrication
- Fire
- Overhaul
- Recovery
- Spills
- First Aid
- Submersion



The following information and procedures in this presentation may not be considered as complete.

*Please consult for detailed information the **Emergency Response Guide!***

Emergency Response

Warning:

- **READY** = Engine may run

 Assume the Prius is **shut OFF**, simply **because** it is **silent**.

- **Always observe** the instrument cluster for the **READY indicator** status to verify whether the vehicle is ON or shut OFF.



Emergency Response

Extrication

- **Immobilize Vehicle**

- Chock wheels + set **parking brake**
- Push **P switch** + confirm **P indicator** is **ON**




- **Disable Vehicle** (HV battery, SRS airbags and fuel pump)

- Push **POWER** button + confirm **READY** is **OFF**
- Disconnect **12V** battery



- ***OR, if POWER button is inaccessible:***

- Disconnect **12 V** battery
- Remove the **IGCT relay**
or HV fuse
(in engine compartment)



Emergency Response

Extrication


- Warning:
 - After disabling the vehicle power is maintained for:
 - **90 seconds** in **SRS** airbag
 - **5 minutes** in **High Voltage** system !
 - High voltage power cables are **orange** = danger !



Emergency Response

Extrication


- High Voltage Safety System



- HV **125 A** fuse protection in Service Plug
- **READY OFF:** stop electric current flow from HV battery
- **READY ON:** **201,6 V** on power cables
- After **READY OFF:** power remains **5 min!**
- Both **cables** (+ and -) are **isolated** from metal chassis



Emergency Response



Extrication



- High Voltage Safety System

- **Ground fault monitor:**

If leak to chassis:

- Master Warning Light ON
- Hybrid Warning Light ON

- **Stop electric current flow:**



- By SRS Airbag sensor assembly
- By circuit breaker sensor in Inverter

Emergency Response

Extrication

- Stabilize Vehicle

- 4 cribbing points, directly under front and rear pillars can be used
- Do not place cribbing under high voltage power cables, exhaust or fuel tank



Emergency Response

Extrication

- Access Patients
 - **Glass** removal: normal procedure
 - **Door** removal / displacement: use conventional tools
 - **Dash** displacement: use conventional tools
 - **Roof** removal: don't cut, SRS curtain airbags!



- Rescue Lift Bags: not under HV power cables, exhaust or fuel tank
- Steering and seat controls (see OM)

Emergency Response

Fire

- › Extinguishing Agent
 - **If used in a large amount, water** has been proven to be a **suitable extinguishing agent**
 - ABC fire extinguisher (Applicable to both oil flames and electric flames)
- › **Initial Fire Attack**
 - Perform a fast, **aggressive attack**
- › Fire in the **HV battery**
 - Warning:
 - NiMH battery electrolyte, a **caustic alkaline** = Potassium hydroxide (**KOH**) & Sodium hydroxide (**NaOH**)
 - HV battery modules in **metal case** (only small access on top)
 - **Never remove cover!** (severe electrical burns, shock or electrocution)



Emergency Response

Fire

› Fire in the HV battery (continued)

- **Offensive fire attack:**

- **Flooding** HV battery pack with **copious** amounts of water

- **Defensive fire attack:**

- **Pull back** at safe distance
- **Water stream or fog** can be used.





Emergency Response

Overhaul

- › Draw attention to the vehicle on which the HV system is being inspected or repaired by placing a **“CAUTION: high voltage do not touch during operation”** sign.


- › If not already done:
 - **Immobilize and disable vehicle**



Emergency Response

Recovery/Recycling NiMH HV battery pack

- › Toyota Service Centers will be informed about the recycling procedures




Emergency Response

Spills

- Prius contains same common automotive fluids, with *exception* of **NiMH electrolyte**.
- NiMH electrolyte is a **caustic alkaline** (pH 13,5) **damaging human tissues**.
- NiMH electrolyte is **absorbed in cell plates** and form a **gel**.
- NiMH electrolyte **will normally not spill or leak** out of module if battery module is cracked.

*(If battery would be overcharged, **gases** are **directed outside the vehicle** through a vent hose connected to each NIMH battery module)*

- **Modules** are **protected by metal** battery pack **case**.
- **Boric acid solution** or **vinegar** is used to **neutralize** a NiMH battery **electrolyte** spill.



Emergency Response

Spills

- Personal **protective equipment:**

- › Splash shield or safety goggles
- › Rubber, latex or Nitrile gloves
- › Apron suitable for alkaline
- › Rubber boots



- **Neutralize NiMH electrolyte:**

- Use **boric acid solution** or **vinegar**

Boric acid solution: **800 g boric acid + 20 l water**

- Check with **red litmus paper:**

- Blue =

- Red = OK



Emergency Response

First Aid

- Personal **protective equipment**: *see previous slide*
- Absorption:
 - › **Rinse** affected areas for **20 minutes**
- Inhalation - non-fire situations:
 - › **No toxic gasses** are emitted **under normal conditions**
- Inhalation – fire situations:
 - › **Toxic gasses** are emitted as a **by-product of combustion**.
 - Wear proper protective equipment
 - Remove patient and administer oxygen
- Ingestion:
 - **Do not induce vomiting**.
 - Allow patient to drink large quantities of water (to dilute electrolyte)



Emergency Response

Submersion

To safely handle a Prius that is fully or partially submerged in water, **disable the high voltage electrical system and SRS airbags**





- **Remove** vehicle from water
- **Drain** water from vehicle if possible
- Follow the **extrication and vehicle disabling procedure** (*see first procedure*)

Roadside Assistance



Towing

- Front wheel drive:
 - **Front wheels off the ground**




Roadside Assistance



12 V battery Jump Start

- 12 V auxiliary battery in luggage compartment



Roadside Assistance




12 V battery Jump Starting (cont.)


- Back door opens electrically:
 - If auxiliary battery is discharged:
You cannot access it!
 - Use Jump Start "+" terminal in engine compartment



Jump Start
Terminal



Roadside Assistance



12 V battery Jump Starting (cont.)

- Connect jumper cables in the order a, b, c, d

Roadside Assistance

Jump start failure



- After jump start failure:
 - One extra trial
- After 2nd failure:
 - Contact TOYOTA Service Center

Roadside Assistance


12 V battery Jump Starting (cont.)

- If you cannot operate back door opener, open back door from inside:

- Open luggage storage box
- Remove the cover
- Pull the lever with back door motor



What is the most important tool when working on a Hybrid vehicle?



**Think first!
Then act!**








Diagnosis

Troubleshooting

Diagnosis

- Data List



| Function | View | System | Bar | Help |
|--|---|---|---|---------|
| Hybrid Control / Data List  | | | | |
| All Data | ▼ | Value | Unit | |
| Engine Coolant Temp | | 68 | F | ▲ |
| Vehicle Spd | | 0 | Km/h | |
| Engine Run Time | | 0 | s | |
| +B | | 11.367 | V | |
| Accel Pedal Pos #1 | | 15.680 | % | |
| Accel Pedal Pos #2 | | 31.752 | % | |
| Ambient Temperature | | 69 | F | |
| Intake Air Temperature | | 75 | F | |
| DTC Clear Warm Up | | 0 | | |
| DTC Clear Run Distance | | 0 | km | |
| DTC Clear Min | | 69 | Min | ▼ |
|  |  |  |  | |
| DTC | Data List | View | Active Test | Utility |

Diagnosis

- DTC & occurrence order

Function View System Bar Help

Hybrid Control / DTC

Current DTC 8

| | | |
|---|-------|--|
| ! | P0A0D | High Voltage System Inter-Lock Circuit High |
| ! | P0AA1 | Hybrid Battery Positive Contactor Circuit Stuck Closed |
| ! | P0AA4 | Hybrid Battery Negative Contacto Circuit Stuck Closed |
| ! | P3105 | Lost Communication with Battery Observation |

Current Pending History Clear

DTC Data List View Active Test Utility

Function View System Bar Help

Hybrid Control / Freeze Frame Data

| Parameter | Value | U... |
|-------------------------|-------|------|
| Exclusive Information 2 | -127 | |
| Exclusive Information 3 | -127 | |
| Exclusive Information 4 | -127 | |
| Exclusive Information 5 | -127 | |
| Exclusive Information 6 | -127 | |
| Exclusive Information 7 | -127 | |
| Occurrence Order | 4 | |
| Inv-T (MG1) aftr IG-ON | 19 °C | |
| Inv-T (MG2) aftr IG-ON | 19 °C | |
| Mtr-T (MG2) aftr IG-ON | 19 °C | |
| Rear Inv-T after IG-ON | 15 °C | |

Exit

DTC Data List View Active Test Utility

•Check all DTC's and there order of occurrence (in FFD)

•Start investigating at the lowest occurrence order

Diagnosis

- Information & Detail code

| Function View System Bar Help | | | | |
|------------------------------------|--|---------|-------------|---------|
| Hybrid Control / Freeze Frame Data | | | | |
| P0AA4 | Hybrid Battery Negative Contactor Circuit Stuck Closed | | | |
| Parameter | Value | U... | | |
| Battery Block Vol -V12 | 21.18 V | | | |
| Battery Block Vol -V13 | 21.14 V | | | |
| Battery Block Vol -V14 | 21.14 V | | | |
| Battery Block Vol -V15 | 21.14 V | | | |
| Information 1 | Avail | | | |
| Information 2 | Not Avl | | | |
| Information 3 | Not Avl | | | |
| Information 4 | Not Avl | | | |
| Information 5 | Not Avl | | | |
| | | Details | | Exit |
| DTC | Data List | View | Active Test | Utility |

| Function View System Bar Help | | | | |
|------------------------------------|--|---------|-------------|---------|
| Hybrid Control / Freeze Frame Data | | | | |
| P0AA4 | Hybrid Battery Negative Contactor Circuit Stuck Closed | | | |
| Parameter | Value | U... | | |
| DTC Clear Min | 0 Min | | | |
| Type of ECU | HV ECU | | | |
| Calculate Load | 0.000 % | | | |
| Throttle Position | 19.208 % | | | |
| Detail Code 1 | 228 | | | |
| Detail Code 2 | 0 | | | |
| Detail Code 3 | 0 | | | |
| Detail Code 4 | 0 | | | |
| Detail Code 5 | 0 | | | |
| | | Details | | Exit |
| DTC | Data List | View | Active Test | Utility |

| Function View System Bar Help | | | | |
|------------------------------------|-----------|------|-------------|---------|
| Hybrid Control / Freeze Frame Data | | | | |
| Parameter | Value | U... | | |
| Information 1 | Avail | | | |
| Information 1 | 228 | | | |
| Generator(MG1) Rev | 0 rpm | | | |
| Motor(MG2) Revolution | 0 rpm | | | |
| Rear Motor Revolution | 0 rpm | | | |
| Generator(MG1) Torq | 0 Nm | | | |
| Motor(MG2) Torq | 0 Nm | | | |
| Rear Motor Torq | 0 Nm | | | |
| Inverter Temp (MG1) | 18 °C | | | |
| Inverter Temp (MG2) | 19 °C | | | |
| Rear Inverter Temp | 15 °C | | | |
| | | | | Exit |
| DTC | Data List | View | Active Test | Utility |

DTC

- Information Code and Exclusive Information

P3000 — 389 ——— 127

DTC

Information
Code

Exclusive
Information

Detection
Item

Detection
Contents

What is Exclusive Information ?

- Information that can be used for analysis for manufacturer
- It memorizes up to seven, and the content is different in each DTC
- It shows the operation / control state of the ECU when DTC is detected

Freeze Frame Data



- Utilize Freeze Frame Data

1. It can be used for the reproduction test by knowing the driving / operating state when the malfunction detected
2. Think about “OCCURRENCE ORDER” = 1 in Information as a main factor

Point! *Be sure to record the FFD and Information, when the vehicle is brought to workshop*

Freeze Frame Data

- Understand the time that a DTC was stored

| Item | Contents |
|-------------------------|--|
| ENG RUN TIME | Elapsed time after starting engine in 1 trip |
| DTC CLEAR WARM | The number of trips after clearing DTCs |
| DTC CLEAR RUN | Drive distance after clearing DTCs <i>(Drive distance after the malfunction detection can be estimated by comparing DTC CLEAR RUN with Data List information)</i> |
| DTC CLEAR MIN | Elapsed time after clearing DTCs |
| OCCURRENCE ORDER | The order when malfunction occurs |

Freeze Frame Data



- Practice
 - Estimate the time series

- Freeze Frame Data -

| Item | Contents |
|---------------|----------|
| DTC CLEARWARM | 30 times |
| DTC CLEAR RUN | 160 km |

- Data List -

| Item | Contents |
|---------------|----------|
| DTC CLEARWARM | 36 times |
| DTC CLEAR RUN | 208 km |